



## Very important !!!

Cover the tub with paint so that it covers about 2/3 to halfway down of the walls of the bathtub. When you use the yellow spreader to lift the paint (*where it is not dyed*) do so ONLY up to 2/3 or half of the wall of the bathtub.



### ***Why is this important?***

If you lift the paint with a yellow spreader up to the entire height of the walls of the tub, it will be covered in paint drips and lines.

If you failed the first time to fill the bathtub with paint up to 2/3 or 1/2 of the height of the wall, then collect the paint from the bottom of the tub in the cup with a yellow spreader, and fill again from the top (don't worry if the paint is distributed evenly, it will become even after several layers).

***\*Before you start to do the bathtub, you can practice first with liquid soap.***

Take liquid soap, pour it into a cup, and try to fill the bathtub (as you would do with real paint). Then, using a yellow spreader, collect the soap in a cup and pour again. Practice as long as you see fit.

***If you have any questions, you can call***

***+1 (224) – 616 – 1766***